



NOTES:

1. IF CLEAN-OUT IS INSTALLED IN DRIVEWAY OR FOR 6" LATERALS, USE CHRISTY G5 TRAFFIC VALVE BOX WITH "SEWER" CAST IN LID (OR APPROVED EQUAL). BOX SHALL HAVE A CONCRETE COLLAR. (SEE DETAIL DS-6 FOR DETAILS OF CONCRETE COLLAR)
2. WHEN PROPERTY LINE IS AT BACK OF WALK, INSTALL CLEAN-OUT BEHIND BACK OF WALK.
3. PROVIDE STOPPER WHEN THERE IS NO ON-SITE LATERAL CONNECTION.
4. FOR NEW LATERALS, THE MATERIAL FOR THE CLEANOUT PIPE SHALL MATCH THE MATERIAL FOR THE LATERAL. SEE CITY'S SPECIFICATIONS FOR MATERIALS. FOR EXISTING LATERALS, THE REPAIR OR REPLACEMENT MATERIAL FOR THE CLEANOUT PIPE SHALL COMPLY WITH STANDARDS FROM THE LATEST EDITION OF THE CALIFORNIA PLUMBING CODE. USE APPROPRIATE COUPLINGS.
5. FOR 8" OR LARGER LATERALS, A STANDARD MANHOLE SHALL BE INSTALLED AT OR NEAR THE PROPERTY LINE.



DRAWN BY: K. TRAN
 CHECKED BY: F. AMIN
 APPROVED BY: G. GOMEZ
 DATE: DECEMBER 2014

**4" & 6" SANITARY SEWER
 CLEAN-OUT**

CITY OF SANTA CLARA

SS-1

PAGE: 37